



RENEWABLE ORGANIC CORE STAIR NOSE

Finishes the end of a step.

1

Floor
Subfloor

Install the flooring leaving a 1-1/4" space from the end of the step for the stair nose installation.

2

Measure and trim to fit.

3

1/4"
Floor
Subfloor

Position the track 1/4" from the floor plank and screw to the subfloor using included screws.

4

Floor
Subfloor

Starting at one end, press the molding into the track inching along the length of the molding. *It will NOT snap in all at once.* You may also use a rubber mallet.