



RENEWABLE
ORGANIC
CORE
REDUCER

Used to fill the gap between two floors of unequal height.

1

Install the flooring leaving a 1-1/8" gap between the two floors for the reducer installation.

2

Measure and trim to fit.

3

Center the track between the flooring with 1/4" spacing between the track and floor plank and screw to the subfloor using included screws.

4

Starting at one end, press the molding into the track inching along the length of the molding. *It will NOT snap in all at once.* You may also use a rubber mallet.