



RENEWABLE ORGANIC CORE T-MOLDING

Used to fill the gap between two floors of equal height. Most common areas are in doorways or to join two floors.

1

1 1/8"

Floor 1

Floor 2

Subfloor

Install the flooring leaving a 1-1/8" gap between the two floors for the t-molding installation.

2

Measure and trim to fit.

3

1/4"

1/4"

Floor 1

Floor 2

Subfloor

Subfloor

Center the track between the flooring with 1/4" spacing between the track and floor plank and screw to the subfloor using included screws.

4

Floor 1

Floor 2

Subfloor

Subfloor

Starting at one end, press the molding into the track inching along the length of the molding. *It will NOT snap in all at once.* You may also use a rubber mallet.